

HAMA-SURF™

ALCOHOL FREE

Hard Surface Cleaner & Disinfectant

READY TO USE

منظف ومطهر الأسطح

Features

Ready to use spray for rapid disinfection of non sensitive hard surfaces including worktops and furniture in hospitals or other places that their enviroment needs to be hygenic.

Effective spectrum

Works as Bactericidal, Virucidal, and Fungicidal.

Instruction of Use

Spray surfaces and objects to be disinfected from a distance of apporximately 30 cm so that they are completely moistened and let the disinfectant volatile or wipe with clean tissue.

Precautions

- Ensure appropriate gloves are worn.
- Keep out reach of children.
- Avoid contact with eyes and if it happens, rinse immediately with water.

Composition

Aqua Water, Benzalkonium Chloride, Nonylphenol Ethoxylate Nonionic Surfactant, Ethanol, Lemon Perfume, Aldehyde and Phenol free.

Hama Code:1111- 005

المصنع كل الحماية للصناعة

**Kol Al-Hamaya
Factory for Industry**

P.O.Box:26316, Riyadh:11486, Saudi Arabia
Tel:+966(11)4458548, Fax:+966(11)4915906

Made in KSA صنع بالمملكة العربية السعودية

e-mail: info@hamaya.co web: www.hamaya.co

الوصف

مطهر جاهز للاستعمال قوي لكافة الأسطح الصلبة مثل الأسطح المعدنية والأثاث في المستشفيات والأماكن التي تحتاج إلى بيئة نظيفة.

التأثير والفاعلية

يقتل معظم أنواع البكتيريا والفيروسات والفطريات.

طريقة الاستعمال

يرش المحلول على الأسطح المراد تطهيرها من مسافة ٣٠ سم تقريبا ثم يترك لفترة قليلة حتى يتطاير أو يمسح بمنديل نظيف.

الاحتياطات

- تأكد من ارتداء القفاز عند الاستخدام.
- يحفظ بعيدا عن متناول الأطفال.
- تجنب ملامسة المحلول للعين وإن تم الملامسة تشطف جيدا بالماء جيدا وفي حال ملامسة المحلول للجلد يغسل بالماء والصابون.



HAMAYA®

